



Supplies Needed:

**Behr Paint
Paint Tray**

**Firm Foam Roller
Lacquer Thinner**



BEHR PREMIUM PLUS WITH STYLE® Metallic AVAILABLE @ HOME DEPOT \$16.97-19.97. This 32oz. container should highlight five vaults.

This versatile, 100% Acrylic Interior water-based product provides the alluring look of metal. Available in a variety of colors, it allows you to give burial vaults an extraordinary finish that enhances and complements our Endurance burial vault. For maximum coverage we recommend you highlight at least 3 vaults in any given setting.

Pre-mixed Colors Available in Home Depot

- 14 Carat No. 741 - [MSDS](#)
- Copper No. 742 - [MSDS](#)
- Silver No. 743 - [MSDS](#)

PREPARATION

Use water or lacquer thinner, wash off any dirt and or dust that may be on the Endurance vault. Once finished allow just a minute to dry. Pour paint into a roller tray and roll the roller in the paint. No taping is need because you can use lacquer thinner to clean areas that are not to be painted.

APPLICATION

Use a firm foam roller to maximize the coverage area of the vault as well as keeping the paint on the higher ridges of the vault. This is called the stippled area.

DRY TIME

Dries to touch in 1 hour at 75°F (23°C) and at 50% humidity. Longer dry time required in cooler temperatures and in higher humidity.

CLEAN UP

To preserve the roller you can wrap your soiled roller in cellophane and place in the freezer. When you are ready to highlight Endurance vaults again take the roller out of the freezer to thaw. Now the roller can be used again. Wash tools with soap and water. Properly dispose of all soiled rags and protect unused product from freezing. To recycle or properly dispose of paint in your community, call 1-800-CLEANUP or visit www.Earth911.org.

STEP 1: Clean surface with a clean towel and lacquer thinner. Mix paint and pour into paint tray.



STEP 2: Place roller in paint and roll off excess paint in tray. You do not want the roller to have too much paint on it. Take roller, applying very little pressure and in one continuous motion apply paint to the stippled areas of the vault. Take your time. The corners are the only smooth areas that get paint.



STEP 3: Wipe down any areas where paint should not be (smooth areas). Below is what the vault should look like.

