



Step 1. Start in one corner and unroll butyl seal pressing seal into groove.



Step 2. Continue around vault with the same roll until you reach the corner you began with.



Step 3. Once you reach the last corner,- overlap the two ends and press the two together making one complete piece.



Step 4. A complete vault with the butyl seal properly applied will look like the picture above.